

PFC SERIES MODELS

BASKET COVER

The basket cover is used to cook any type of floating food product. It ensures that any food product remains below the oil level. (Note: it is designed for the XL basket only.)



Simply set the basket cover into the XL Basket as per the diagram below.



PHONE: 403-255-7712 TOLL FREE: 800-265-7711

ADDRESS: 615 71st Avenue SE, Calgary, AB, Canada T2H 0S7

FAX: 403-255-1725

E-MAIL: profits@perfectfry.com
WEB: www.perfectfry.com
©2003 PERFECT FRY COMPANY

